



Curt Manufacturing Marketing Bulletin #909

November 20, 2009

New Releases

Part#	Years	Make	Model	Type	Capacity WC/TW	Capacity WD/TW	Inst. Time	Drill	PC	UPC	UPS Wht.	Exposed/Concealed	Application Notes
Class 1 & 2 Receiver Hitches													
11170	2008-2009	MINI	Clubman	Including "S" models	2000/200	n/a	60	Yes	35	612314111701	46	Concealed	New hitch application
11280	2003-2007	Subaru	Baja	Sport & Turbo	2000/200	n/a	20	No	53	612314112807	38	Exposed	Replacing 11279
12000	2006-2010	Toyota	Rav4	All	3500/300	n/a	15	No	33	612314002467	46	Exposed	New hitch application
12072	2007-2010	Ford	Edge	All	3500/350	n/a	45	Yes	45	612314120727	38	Exposed	New hitch application
	2007-2010	Lincoln	MKX	All	3500/350	n/a	45	Yes	45	612314120727	38	Exposed	New hitch application
12296	2010-2010	Ford	Taurus	Including SHO	3500/300	n/a	30	No	53	612314122967	63	Concealed	New hitch application
12298	2010-2010	Subaru	Legacy	Sedan	3500/350	n/a	60	Yes	45	612314122981	36	Exposed	New hitch application
Class 3 Receiver Hitches													
13076	2010-2010	Ford	Transit Connect	All	3500/350	4000/400	30	No	49	612314001576	51	Exposed	New hitch application
13268	2010-2010	Volvo	XC60	All	4000/400	4500/450	60	No	37	612314132683	38	Concealed	New hitch application
Front Mount Hitches													
31008	2008-2010	Ford	Super Duty	Full Size Pickup Trucks 2 & 4 Wheel Drive	5000/500	n/a	20	No	37	612314002573	52	Concealed	Replacing 31355
Electrical													
51110	n/a	n/a	n/a	Venturer brake controller w/ time based activation	n/a	n/a	n/a	n/a	n/a	612314511105	1.2	n/a	Controls any trailer w/ 2 to 6 electric brakes (1 to 3 axles)
51438	2010-2010	Dodge	Ram 1500	w/ OEM tow package	n/a	n/a	5	n/a	n/a	612314002917	0.25	n/a	Bulk OEM brake control harness
51439	2010-2010	Dodge	Ram 1500	w/ OEM tow package	n/a	n/a	5	n/a	n/a	612314002924	0.35	n/a	Packaged OEM brake control harness
51516	n/a	n/a	n/a	Quick plug to splices for vehicles w/o OEM	n/a	n/a	n/a	n/a	n/a	612314515165	0.28	n/a	Packaged brake control wiring harness
56084	2009-2009	Nissan	Cube	All	n/a	n/a	20	n/a	n/a	612314560844	0.765	n/a	T-Connector
56092	2007-2009	Chevy/GMC	Aveo	Sedan	n/a	n/a	15	n/a	n/a	612314001941	0.63	n/a	T-Connector
56093	2010-2010	Ford	Taurus	Including SHO	n/a	n/a	45	n/a	n/a	612314001972	1.535	n/a	T-Connector
56094	2010-2010	Chevy/GMC	Equinox	All	n/a	n/a	20	n/a	n/a	612314002122	0.51	n/a	T-Connector
	2010-2010	Chevy/GMC	Terrain	All	n/a	n/a	20	n/a	n/a	612314002122	0.51	n/a	T-Connector
56095	2010-2010	Lincoln	MKT	All	n/a	n/a	45	n/a	n/a	612314002542	1.58	n/a	T-Connector
56096	2010-2010	Cadillac	SRX	w/ OEM tow package	n/a	n/a	5	n/a	n/a	612314002948	0.5	n/a	Replacement OEM 4-flat
Ball Mounts													
45000	n/a	n/a	n/a	Class II ball mount 3-1/8" rise / 13-1/2" long	3500/350	n/a	n/a	n/a	n/a	612314001583	7.85	n/a	Not to be used in the drop position
Accessories													
18050	n/a	n/a	n/a	Bike rack strap with cambuckle for added support and stability	n/a	n/a	n/a	n/a	n/a	612314105304	1.4	n/a	CURT Manufacturing recommends the use of this bike rack support strap w/ all hitch applications

Carryovers

Part#	Years	Make	Model	Type
Class 1 & 2 Receiver Hitches				
11090	2007-2010	Volkswagen	EOS	
11094	2006-2010	Kia	Rio	
11096	2007-2010	Volkswagen	Passat	4-Dr Wagon
11112	2008-2010	Saturn	Astra	3 & 5-Dr
11130	2009-2010	MINI	Cooper	"S" model
11132	2000-2010	Chrysler	PT Cruiser	
11160	2007-2010	MINI	Cooper	Except w/ center or dual exhaust
11188	2006-2010	Audi	A5	Coupe, Except 2.0T (Turbo)
11192	2006-2010	Audi	A3	Sportback
11194	2008-2010	BMW	535xi	Wagon
11195	2009-2010	Audi	A4 Avant	Wagon
11307	2003-2010	Cadillac	CTS	
	2005-2010	Cadillac	STS	
11315	2008-2010	Subaru	Impreza	Wagon (5 Door)
11338	2006-2010	Mazda	5	Minivan
11342	2007-2010	Nissan	Sentra	Sedan
11352	2007-2010	Nissan	Altima	Sedan
11357	2008-2010	Nissan	Altima	Coupe
11372	2006-2010	Lexus	IS 250 & IS 350	

Part#	Years	Make	Model	Type	
Class 1 & 2 Receiver Hitches Continued...					
11438	2004-5-2010	Volvo	S40	Sedan	
11510	2008-2010	Infiniti	EX 35 Journey		
11771	2007-2010	BMW	328i & 328xi	Wagon	
11829	2008-2010	Volvo	C30	3-Dr Liftback	
12012	1994-2010	Mazda	B-Series	Pickup Truck	
12058	2006-2010	Cadillac	DTS		
12060	2005-2010	Mazda	Tribute		
12093	2007-2010	Mazda	CX-7		
12126	2004-2010	Kia	Sportage		
12130	1979-2010	Ford	Crown Victoria		
12240	2005-2010	Chrysler	300C		
12245	2008-2010	Jeep	Liberty		
12247	2008-2010	Nissan	Rogue		
12254	2009-2010	Volkswagen	Tiguan		
12255	2007-2010	Jeep	Compass		
	2007-2010	Jeep	Patriot		
12341	2009-2010	Toyota	Venza	Including AWD	
12343	2007-2010	Lexus	ES 350		
Class 3 Receiver Hitches					
13019	1994-2010	Mazda	B-Series	Pickup truck	
13055	2000-2010	Ford	Econoline	Full-size van	
13077	2007-2010	BMW	X5		
13138	1994-2010	Mazda	B-Series	Pickup truck	
13185	2008-2010	Nissan	Rogue		
13208	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	6' & 8' beds	
13210	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	6' & 8' beds	
13211	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	6' & 8' beds	
13213	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	6' & 8' beds w/ Tommy Gate Lift	
13220	2007-2010	Audi	Q7		
	2004-2010	Volkswagen	Touareg		
13228	2005-2010	Dodge	Dakota		
13229	2005-2010	Dodge	Dakota		
13230	2005-2010	Dodge	Dakota		
13241	2005-2010	Nissan	Frontier		
	2009-2010	Suzuki	Equator		
13245	2008-2010	Jeep	Liberty		
13251	2005-2010	Jeep	Grand Cherokee		
13252	2004-2010	Chevy/GMC	Canyon		
	2004-2010	Chevy/GMC	Colorado		
13266	2008-2010	Volvo	XC70		
13301	2007-2010	Chevy/GMC	Silverado/Sierra 1500	New Body	
13322	2007-2010	Chevy/GMC	Silverado/Sierra 1500	New Body	
13333	2009-2010	Dodge	Ram 1500		
13339	2007-2010	Chevy/GMC	Silverado/Sierra 1500	New Body	
13342	2006-2010	Mercedes	ML 350	Except BlueTEC models	
13345	2006-2010	Kia	Sedona	Long Wheel Base (119")	
13349	2007-2010	Kia	Sedona	Short Wheel Base (114")	
13356	2009-2010	Toyota	Venza	Including AWD	
13367	2007-2010	Toyota	FJ Cruiser		
13374	2009-2010	Dodge	Ram 1500		
13414	2006-2010	Jeep	Commander		
13432	2007-2010	Jeep	Wrangler	Including Unlimited	
13465	2005-2010	Chrysler	300C		
13509	2006-2010	Toyota	Rav4		
13526	2004-2010	Kia	Sportage		
13534	2008-2010	Toyota	Highlander		
13536	2007-2010	Acura	RDX		
13545	2007-2010	Hyundai	Veracruz		
13547	2009-2010	Ford	Flex	Hitch is CWSL	
13548	2007-2010	Jeep	Compass		
	2007-2010	Jeep	Patriot		
13551	2009-2010	Ford	Flex		
13554	2009-2010	Infiniti	FX35 & FX50		
13573	2004-2010	BMW	X3		
13575	2007-2010	Mazda	CX-9		
13577	2009-2010	Nissan	Murano		
13593	2007-2010	Mazda	CX-7		
13650	2005-2010	Mazda	Tribute		
13707	1979-2010	Ford	Crown Victoria		

Part#	Years	Make	Model	Type	
Class 4 & 5 Receiver Hitches					
14055	2000-2010	Ford	Econoline	Full-size van	
14070	2007-2010	Dodge	Ram	Cab & Chassis	
14211	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	6' & 8' beds	
14301	2007-2010	Chevy/GMC	Silverado/Sierra 1500	New Body	
14374	2009-2010	Dodge	Ram 1500		
15211	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	6' & 8' beds	
15301	2007-2010	Chevy/GMC	Silverado/Sierra 1500	New Body	
XDC & IDC Receiver Hitches					
15512	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	8' bed w/ factory cutout bumper (OEM replacement)	
15513	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	8' bed	
15521	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	6' bed	
15522	2007-2010	Chevy/GMC	Silverado/Sierra 1500	New Body	
15530	2007-2010	Dodge	Ram	Cab & Chassis	
15572	2009-2010	Dodge	Ram 1500		
15602	2001-2010	Chevy/GMC	Silverado/Sierra 2500HD/3500	6' & 8' beds	
15605	2007-2010	Dodge	Ram	Cab & Chassis	
Front Mount Hitches					
31322	2007-2010	Chevy/GMC	Silverado/Sierra 1500	New Body 2 & 4 WD	
31374	2009-2010	Dodge	Ram 1500		
Electrical					
55513	2005-2010	Toyota	Tacoma		

Added Hitch Coverage

The following are existing CURT hitch numbers with additional application coverage.					
11390	2010-2010	Lincoln	MKZ	Sedan	

Catalog Corrections, Notes, & Clarifications

- Hitch number 11380 for a 2005-2008 Chevrolet Corvette will not fit models with Dual Mode Exhaust.
- Part number 51516 on page 154 of the 2010 catalog is also available as a bulk product. Part number is 51515, UPC: 612314515158, Shipping Weight: .195
- Hitch number 11043 for a 1999-2003 Mazda Protégé will not fit models with plastic bumpers.
- Hitch number 15512 for a 2001-2009 Chevrolet/GMC Silverado/Sierra 2500HD/3500 will only fit a 8' bed. Previously it was cataloged to fit 6' & 8' beds.
- Hitch number 11188 for a 2008-2010 Audi A5 will not fit the 2.0 liter turbo engine for the 2010 models.
- Hitch number 11109 for a 1995-2005 Pontiac Sunfire will not fit a LS Sport model.
- Hitch number 11279 for a 2003-2007 Subaru Baja is now CWSL and is replaced with hitch 11280.
- Hitch number 31355 for 2008-2010 Ford Super Duty pickup trucks is now CWSL and is replaced with hitch number 31008.

We thank you for your business!